



# HÆGER

## Sous-chef 20 MW-70B.007A



(478 x 382 x 288 mm)

## Features

Características / Características / Caracteristiques

**6**  
**POWER**  
**Settings**

### 6 Power Settings

6 Níveis de Potência  
6 Niveles de Potencia  
6 Niveaux de Puissance



### 30 Minutes timer

Temporizador de 30 minutos  
Temporizador de 30 minutos  
Minuterie de 30 minutes



**DEFROST**

### Defrost Function

Função de Descongelação  
Función de Descongelación  
Fonction de Dégivrage



### Cooking End Signal

Aviso sonoro indicador de fim  
Aviso sonoro indicador de final  
Avertisseur sonore indicateur de fin



**Inner Light**

### Inner light

Iluminação interior  
Iluminación interior  
Eclairage intérieur



**24.5cm**

### 24.5cm glass rotating plate

Prato rotativo em vidro de 24.5cm  
Plato giratorio en vidrio de 24.5cm  
Plateau rotatif en verre avec 24.5cm



**Pull handle**

### Pull handle to open door

Puxar a alça para abrir a porta  
Tire de la manija para abrir la puerta  
Tirer la poignée pour ouvrir la porte



**700 W**

### Power: 700 Watts - 230V~, 50Hz

Potência: 700 Watts - 230V~, 50Hz  
Potencia: 700 Watts - 230V~, 50Hz  
Puissance: 700 Watts - 230V~, 50Hz



#### 6 Power Settings

6 Níveis de Potência  
6 Niveles de Potencia  
6 Niveaux de Puissance



#### 30 Minutes timer

Temporizador de 30 minutos  
Temporizador de 30 minutos  
Minuterie de 30 minutes



#### 24.5cm glass rotating plate

Prato rotativo em vidro de 24.5cm  
Plato giratorio en vidrio de 24.5cm  
Plateau rotatif en verre avec 24.5cm



#### Pull handle to open door

Puxar a alça para abrir a porta  
Tire de la manija para abrir la puerta  
Tirer la poignée pour ouvrir la porte

Cavity dimensions: W307 x D306 x H217.5 (mm)  
Unit dimensions: W451 x D345 x H256.5 (mm)  
Net weight: 10.1 Kg

Meet the family

Código EAN



5 1608475 101634 9



1 Unidade (478 x 382 x 288mm)

